



Data

AS index	S0041
Kategória	Štartéry
Výrobca	AS-PL
Náhrada za	Bosch

Vlastnosti produktu

Rozmer A [mm]	89
Rozmer B [mm]	27.5
Príkonnosť [kW]	4.0
Napätie [V]	24
Počet otvorov v hlavici	3
Počet zubov (zapadá do)	10
Otáčka štartéra	CW



Referenčné číslo (51)

Number	Výrobca
AES7147	AUTOELECTRO
0001368016	BOSCH
0001368081	BOSCH
0986011290	BOSCH
0986011291	BOSCH
0986017860	BOSCH
0986017863	BOSCH
B001816006	BOSCH
111640	CARGO
CST10618AS	CASCO
CST10618ES	CASCO
CST10659AS	CASCO
CST10659GS	CASCO
CST10659RS	CASCO
8662	CEVAM
19024264	DELCO
DRS1290	DELCO

DRS7860	DELCO
EAA-121140	EAA
33550	EAI
13140	EFEL
45-1091	ELSTOCK
8811290	FRIESEN
CS269	HC PARTS
8EA726038-001	HELLA
11.130.537	ISKRA / LETRIKA
11.131.143	ISKRA / LETRIKA
11.131.177	ISKRA / LETRIKA
AZJ3160	ISKRA / LETRIKA
AZJ3387	ISKRA / LETRIKA
AZJ3393	ISKRA / LETRIKA
IS0537	ISKRA / LETRIKA
22.0269	LAUBER
28.0269	LAUBER
28.0269M	LAUBER
LRS00747	LUCAS
51.26201-7095	MAN
51.26201-7119	MAN
51.26201-7153	MAN
51.26201-9140	MAN
81368001	MONARK
81388081	MONARK
858318	PRESTOLITE
861037	PRESTOLITE
551.001.103	PSH
RNL1129	RNL
2011-040RS	RS
455532	VALEO
458336	VALEO
30115N	WAI / TRANspo
STR22072	WOODAUTO

Využitie

MAN

Značka	Model	Typ	let	Poznámky
MAN	10.136 5.7	(G)[D0226MF]	09.1981-09.1987	
MAN	10.150 4.6	(L2000)[D0824LFO]	02.1995-01.1996	
MAN	10.150 5.7	(G90)[D0226MF/Silent]	05.1990-10.1993	
MAN	10.150 6.9	(G90)[D0826GF01]	09.1987-10.1993	
MAN	10.163 4.6	(L2000)[D0824LFL02]	01.1995-12.1995	
MAN	10.163 4.6	(L2000)[D0824LFL06]	05.1994-03.1997	
MAN	10.163 4.6	(L2000)[D0824LFL09]	03.2000-	
MAN	10.220 6.9	(L2000)[D0826LFL03]	02.1995-02.2001	
MAN	10.223 6.9	(L2000)[D0826LFL02](L2000)[D0826LFL06]	08.1994-06.1996	
MAN	10.224 6.9	(L2000)[D0826LFL03]	01.1995-02.2001	
MAN	12.152 6.9	(M90)[D0826F01](M90)[D0826F02]	12.1988-05.1994	
MAN	12.192 6.9	(M90)[D0826LFL01](M90)[D0826LFL05](M90)[D0826LFL07]	07.1990-06.1996	
MAN	12.222 6.9	(M90)[D0826LFL11]	05.1994-06.1996	
MAN	12.224 6.9	(M2000L)[D0826LFL03]	08.1995-08.2001	
MAN	12.232 6.9	(M90)[D0826LFL02](M90)[D0826LFL06](M90)[D0826LFL08]	08.1988-06.1996	
MAN	12.262 6.9	(M90)[D0826LFL13]	08.1995-06.1996	

MAN	12.272 6.9	(M90)[D0826LF04]	10.1992-06.1996
MAN	14.152 6.9	(M90)[D0826F01]	12.1988-05.1994
MAN	14.152 6.9	(M90)[D0826F02]	12.1988-04.1994
MAN	14.192 6.6	(M90)[D0826TF]	08.1988-06.1990
MAN	14.224 6.9	(M2000L)[D0826LFL03](M2000L)[D0826LFL10](M2000M)[D0826LF18]	08.1995-09.2001
MAN	14.225 6.9	(M2000L)[D0836LFL02]	09.2000-09.2001
MAN	14.232 6.9	(M90)[D0826LF/217/Silent]	05.1990-04.1995
MAN	14.232 6.9	(M90)[D0826LF02](M90)[D0826LF06](M90)[D0826LF08]	08.1988-06.1996
MAN	14.264 6.9	(M2000L)[D0826LFL09](M2000M)[D0826LF17]	08.1995-09.2001
MAN	15.224 6.9	(M2000L)[D0826LFL03](M2000L)[D0826LFL10]	08.1995-09.2001
MAN	15.225 6.9	(M2000L)[D0836LFL02]	09.2000-09.2001
MAN	15.264 6.9	(M2000L)[D0826LFL09]	08.1995-09.2001
MAN	17.192 6.6	(M90)[D0826TF]	02.1989-06.1990
MAN	17.192 6.9	(M90)[D0826LF01](M90)[D0826LF05](M90)[D0826LF07]	07.1990-01.1991
MAN	17.232 6.9	(M90)[D0826LF/217/Silent]	05.1990-04.1995
MAN	17.272 6.9	(M90)[D0826LF04]	10.1992-05.1995
MAN	18.224 6.9	(M2000L)[D0826LFL03](M2000L)[D0826LFL10](M2000M)[D0826LF17](M2000M)[D0826LF18]	08.1995-09.1999
MAN	18.224 6.9	(M2000L)[D0826LFL03](M2000L)[D0826LFL10](M2000M)[D0826LF17](M2000M)[D0826LF18]	08.1995-09.2001
MAN	18.264 6.9	(M2000L)[D0826LFL09](M2000M)[D0826LF17]	08.1995-09.2001
MAN	24.192 6.9	(M90)[D0826LF01](M90)[D0826LF05](M90)[D0826LF07]	07.1989-06.1996
MAN	24.232 6.9	(M90)[D0826LF/217/Silent]	05.1990-04.1995
MAN	24.232 6.9	(M90)[D0826LF02]	07.1989-06.1996
MAN	25.224 6.9	(M2000M)[D0826LF15]	08.1995-03.1997
MAN	25.224 6.9	(M2000M)[D0826LF18]	08.1995-09.1999
MAN	25.264 6.9	(M2000M)[D0826LF17]	08.1995-09.2001
MAN	6.100 4.6	(G90)[D0824GF](G90)[D0824GF01](G90)[D0824GF02]	09.1987-10.1993
MAN	6.90 3.8	(G)[D0224MF]	10.1979-09.1987
MAN	8.100 4.6	(G90)[D0824GF01](G90)[D0824GF02]	09.1987-10.1993
MAN	8.113 4.6	(L2000)[D0824LFL04]	08.1995-05.2000
MAN	8.136 5.7	(G)[D0226MF]	03.1982-07.1988
MAN	8.150 4.6	(L2000)[D0824LFO]	02.1995-07.1998
MAN	8.150 5.7	(G90)[D0226MF]	05.1990-10.1993
MAN	8.163 4.6	(L2000)[D0824LFL02]	01.1995-09.2001
MAN	8.163 4.6	(L2000)[D0824LFL06]	05.1994-03.1997
MAN	8.163 4.6	(L2000)[D0824LFL07]	08.1995-03.2001
MAN	8.163 4.6	(L2000)[D0824LFL09]	03.1997-09.2002
MAN	8.170 5.7	(G90)[D0226MCFO/170]	02.1989-10.1993
MAN	8.220 6.9	(L2000)[D0826LFL03]	04.1995-09.2001
MAN	8.223 6.9	(L2000)[D0826LFL02](L2000)[D0826LFL06]	05.1994-06.1996
MAN	8.224 6.9	(L2000)[D0826LFL03]	08.1994-09.2001
MAN	8.90 3.8	(G)[D0224MF]	10.1979-09.1987
MAN	9.136 5.7	(G)[D0226MF]	10.1979-08.1988
MAN	9.150 5.7	(G90)[D0226MF/Silent]	05.1990-10.1993
MAN	9.150 6.9	(G90)[D0826GF01]	07.1988-10.1993
MAN	9.150 6.9	(G90)[D0826GF03]	09.1987-10.1993
MAN	9.153 4.6	(L2000)[D0824LFL01]	10.1993-12.1995
MAN	9.153 4.6	(L2000)[D0824LFL05]	08.1995-06.1996
MAN	9.163 4.6	(L2000)[D0824LFL02]	05.1994-12.1995
MAN	9.163 4.6	(L2000)[D0824LFL06]	05.1994-03.1997
MAN	9.163 4.6	(L2000)[D0824LFL09]	03.1997-09.1999
MAN	9.170 5.7	(G90)[D0226MCFO/170]	02.1989-10.1993
MAN	9.223 6.9	(L2000)[D0826LFL02](L2000)[D0826LFL06]	05.1994-06.1996
MAN	9.224 6.9	(L2000)[D0826LFL03]	05.1994-09.2001
MAN	EM 223 6.9	[D0826LUH12][D0826LOH15]	07.2001-09.2001
MAN	NM 152 6.9	[D0826OH02]	05.1990-10.1993



MAN	NM 222 6.9	[D0826LOH15]	02.1996-07.1998	
MAN	NM 223 6.9	[D0826LUH12][D0826LOH15]	07.1998-09.1999	
MAN	SM 152 6.9	[D0826OH02]	11.1987-04.1994	
MAN	SM 182 6.9	[D0826LOH01][D0826TOH]	11.1987-02.1995	
MAN	SM 192 6.9	[D0826LOH01][D0826TOH]	11.1987-02.1995	